

Intel Assembly

Data Movement Instruction:

- mov (covered already)
- push, pop
- lea (mov and offset)
- lds, les, lfs, lgs, lss
- movs, lods, stos
- ins, outs
- xchg, xlat
- lahf, sahf (not covered)
- in, out
- movsx, movzx
- bswap
- cmov



Stack Instructions

There are six forms of the **push** and **pop** instructions.

Register, memory (memory-to-memory copy), immediate, segment register, flags, and all registers

push:

The source of the data may be:

Any 16- or 32-bit register, immediate data, any segment register, any word or doubleword of memory data

pushad pushes **eax**, **ecx**, **edx**, **ebx**, **esp**, **ebp**, **edi** and **esi** where the value of **esp** saved on the stack is its value before the **pushad**.

pop:


The source of the data may be:

Any 16- or 32-bit register, any segment register (except for **cs**), any word or doubleword of memory data.



Stack Instructions

push:



Address Loading Instructions

Load-Effective Address.

- **lea:**

Loads any 32-bit register with the address of the data, as determined by the instruction addressing mode.

- **lds** and **les:**

Load a 32-bit offset address and then **ds** or **es** from a 48-bit memory location.

- **lfs**, **lgs** and **lss** (80386 and up):

Load any 32-bit offset address and then **fs**, **gs** or **ss** from a 48-bit memory location.

lea *eax*, [*ebx+ecx*4+100*] ; Loads *eax* with computed address.

lds *edi*, LIST ; Loads *edi* and *ds*.

lfs *esi*, DATA ; Loads *esi* and *fs*.

NOTE: **lea** calculates the **ADDRESS** given by the right arg and stores it in the left arg!



Address Loading Instructions

Load-Effective Address.

lea versus **mov**:

```
lea ebx, [edi] ;Load the contents of edi into ebx. (1)
mov ebx, [edi] ;Load the value at edi into ebx. (2)
mov ebx, edi ;Move the contents of edi into ebx. (3)
```

1 and 3 are equivalent.

So what are the differences?

3 is faster than 1 and is preferred.

However, **mov** only works with single args and cannot be used with *LIST*[edi].

lea can take any address, e.g., **lea esi, [ebx + edi]**.

String Operations**movs, lods, stos, ins, outs**

Allow data transfers of a byte, a word or a double word, or if repeated, a block of each of these.

The *D* flag-bit (direction), **esi** and **edi** are implicitly used.

- *D* = 0: Autoincrement **edi** and **esi**.

Use **cld** instruction to clear this flag.

- *D* = 1: Autodecrement **edi** and **esi**.

Use **std** instruction to set it.

edi:

Accesses data in the extra segment. Can NOT override.

esi:

Accesses data in the data segment. Can be overridden with segment override prefix.



String Operations

lods:

Lloads **al**, **ax** or **eax** with data stored at the data segment (or extra segment) + offset given by **esi**.

esi is incremented or decremented afterwards:

```
lodsb      ;al=ds:[esi]; esi=esi+/-1
lodsd      ;eax=ds:[esi]; esi=esi+/-4
es lodsb DATA ;Override ds.
```

stosb:


Stores **al**, **ax** or **eax** to the extra segment (**es**) + offset given by **edi**. **es** cannot be overridden.

edi is incremented or decremented afterwards:

```
stosb      ;es:[edi]=al; edi=edi+/-1
stosd      ;es:[edi]=eax; edi=edi+/-4
```



String Operations
An example



String Operations

rep prefix:

Executes the instruction **ecx** times.

```
mov edi, 0           ;Offset 0.  
mov ecx, 25*80       ;Load count.  
mov eax, 0720H       ;Load value to write.  
rep stosw
```

NOTE: **rep** does not make sense with the **lods** instruction.

movs:

Moves a byte, word or doubleword from data segment and offset **esi** to extra segment and offset **edi**.

Increments/decrements both **edi** and **esi**:

```
movsb    ;es:[edi]=ds:[esi]; edi+/-=1; esi+/-=1  
movsd    ;es:[edi]=ds:[esi]; edi+/-=4; esi+/-=4
```

String Operations**ins/out:**

Transfers a byte, word or doubleword of data from/to an I/O device into/out of the extra/data segment + offset **edi/esi**, respectively.

The I/O address is stored in the **edx** register.

```
insb           ;es:[edi]=[edx]; edi+/-=1
insd           ;es:[edi]=[edx]; edi+/-=4
insw W1, W2   ;es:[edi]=[edx]; edi+/-=2; esi+/-=2
outsb         ;[edx]=ds:[esi]; esi=esi+/-1
```

Miscellaneous Data Transfer Operations:**xchg:**

Exchanges the contents of a register with the contents of any other register or memory location.

It can NOT exchange segment registers or memory-to-memory data. Byte, word and doublewords can be exchanged using any addressing mode (except immediate, of course).

```
xchg edx, esi ;Exchange edx and esi
```



Miscellaneous Data Transfer Operations

in and out:

Transfers a byte, word or doubleword of data from/to an I/O device into/out of **al**, **ax** and **eax**, respectively.

Memory operations are not available (as they are in **ins** and **outs**):

```
in  al, port      ;8-bits are saved to al from I/O port port.
out port, eax     ;32-bits are written to port port from eax.
```

- Two forms: Fixed-port addressing (8-bit port value encoded in instruction) and variable-port addressing (16-bit port value stored in **dx**).

in and out example:

```
in  al, 61H
or  al, 3
out 61H, al
mov cx, 1000H
L1: loop L1
in  al, 61H
and al, 0FCH
out 61H, al
      ;Read port 61H (speaker).
      ;Set rightmost two bits.
      ;Turn on the speaker.
      ;Delay count.
      ;Time delay.
      ;Read port 61H.
      ;Clear rightmost two bits.
      ;Speaker off.
```

The old contents of the higher-order bits of the port are preserved.



Miscellaneous Data Transfer Operations

movsx and **movzx** (80386 and up only):

Move-and-sign-extend and Move-and-zero-extend:

movsx *cx*, *bl* ; Sign-extends *bl* into *cx*

movzx *eax*, *DATA2* ; Zero extends word at *DATA2* in *eax*.

bswap (80486 and up only):

Swaps the first byte with the fourth, and the second byte with the third.

Used to convert between little endian and big endian:



cmov (Pentium and up only):

These instructions move data only if a condition is true.

Conditions are set by a previous instruction and include *Carry*, *Zero*,

Sign, *Overflow* and *Parity*:

cmovz *eax*, *ebx* ; Move if Zero flag is set else do nothing.

There are many variations of this instruction (see Appendix B of text).

Assembler Directives

Segment Override Prefix:

Allows the programmer to override the default segment.

```
es outsb  
es cmps
```

Code and Data Segment Declarations:

```
section .data           ;Define a data segment.  
section .text          ;Define a code segment.
```

Procedure Calls

```
push args...           ;Push the arguments on stack.  
call procedure_name   ;Call the procedure  
add esp, #             ;Restore the stack pointer.
```

See nasm slides and documentation on other details.

